## **Technical Data Sheet**

Advanced Engineering Ltd
Guardian House, Stroudley Road

Basingstoke, Hampshire, RG24 8NL. UK Tel +44(0)1256 460300 www.advancedengineering.co.uk



## StayClean™ Mini Tablets

## **Condensate tray bacterial control treatment**



**Special Features** 

- · Controls odours
- Reduces sludge build-up
- · Minimises risk of blockages

StayClean™ Mini Tablets are an inexpensive, easy-to-use, long-lasting condensate tray treatment. The tablets will control odours and prevent sludge build-ups and blockages in the condensate tray and drain. They are safe to use, non-corrosive and – being totally soluble – leave no residues to create further problems.

#### PRODUCT SPECIFICATION

| Name                        | StayClean™ Mini Tablets |
|-----------------------------|-------------------------|
| Product Code                | S010105GB               |
| Packing Quantity (ml, L)    | 20 x 20 tablet bags     |
| Packing Size (L x H x D cm) | 23 x 15 x 14            |
| Shipping Weight (kg)        | 1.12                    |
| Shipping Volume (m3)        | 0.0045                  |
| Soils                       | Control bacteria,       |
|                             | mould & fungus          |

## Directions of use







Simply place the tablet in the tray at the highest end, and adjacent to the coil, so that the resulting treatment will cover the entire tray. For larger systems multiple tablets may be used. For initial applications, or where the tray and drain are severely contaminated, double the suggested treatment rate.

One tablet will treat a 2-3kW system and will last for a month. Multiple tablets can be used in larger systems for maximum flexibility.

#### Disnosal

Product and packaging: Dispose of as normal industrial waste.



# StayClean™ Mini Tablets Danger Contains Biocide

H315: Causes skin irritation. H318: Causes serious eye damage. P260: Do not breathe dust. P262: Do not get in eyes, on skin, or on clothing. P280: Wear protective gloves. P301+310: IF SWALLOWED: Immediately call a POISON CENTER/doctor. P302+350: IF ON SKIN: Gently wash with plenty of soap and water. P305+351+338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

### **Preparation Type:**

Solid

### **Contains Biocide:**

Alkyl (C12-18) dimethyl benzyl ammonium chlorides, 1 g/100g

Approved by







